

Double Hungs

Width		R.O.		Width		R.O.		Width		R.O.		Height	R.O.		
1'8"	22"	1'8"	43-1/2"	1'8"	65"	3'2"	41-1/4"	2'0"	26"	2'0"	77"	3'10"	49-1/4"	4'2"	53-1/4"
2'4"	30"	2'4"	59-1/2"	2'4"	89"	4'6"	57-1/4"	2'8"	34"	2'8"	101"	5'2"	65-1/4"	4'6"	57-1/4"
2'8"	34"	2'8"	67-1/2"	2'8"	101"	5'6"	69-1/4"	3'0"	38"	3'0"	113"	6'2"	77-1/4"	5'2"	65-1/4"
3'0"	38"	3'0"	75-1/2"	3'0"	113"			3'4"	42"	3'4"	125"				
3'4"	42"	3'4"	83-1/2"	3'4"	125"										

Picture Window with Flankers

Height	R.O.
3'2"	41-1/4"
3'10"	49-1/4"
4'2"	53-1/4"
4'6"	57-1/4"
5'2"	65-1/4"
5'6"	69-1/4"
6'2"	77-1/4"

Flanker Width	P.W. Width	R.O.
1'8"	3'0"	81"
1'8"	3'4"	85"
1'8"	4'0"	93"
1'8"	5'0"	105"
1'8"	6'0"	117"
2'0"	3'0"	89"
2'0"	3'4"	93"
2'0"	4'0"	101"
2'0"	5'0"	113"
2'0"	6'0"	125"
2'4"	3'0"	97"
2'4"	3'4"	101"
2'4"	4'0"	109"
2'4"	5'0"	121"
2'4"	6'0"	133"
2'8"	3'0"	105"
2'8"	3'4"	109"
2'8"	4'0"	117"
2'8"	5'0"	129"
2'8"	6'0"	141"
3'0"	3'0"	113"
3'0"	3'4"	117"
3'0"	4'0"	125"
3'0"	5'0"	137"
3'0"	6'0"	149"

Stationary Units

Height	R.O.
3'2"	41-1/4"
3'10"	49-1/4"
4'2"	53-1/4"
4'6"	57-1/4"
5'2"	65-1/4"
5'6"	69-1/4"
6'2"	77-1/4"

Width	R.O.
3'0"	38"
3'4"	42"
4'0"	50"
5'0"	62"
6'0"	74"

Height Adder w/ Transom

Call Height	Add to R.O. of Base Unit
1'0"	13-1/2"
1'2"	15-1/2"
1'6"	19-1/2"
2'0"	25-1/2"
2'6"	31-1/2"

Ensure that all rough openings are framed square, level and plumb

Ensure that all units are properly shimmed at the check rail

